

Where do I place my jack to lift the cart?

On Non-Lifted Carts there are several Lifting points to safely lift your cart.



Rear of cart-cross brace of frame just behind the rear bumper.



Behind the front wheels on either side of the frame.



Front lower control arm mounting points on both sides.

On lifted carts there are several Lifting points to safely lift your cart.



Rear of cart-cross brace of frame just behind the rear bumper.



Anywhere along the side of the frame as long as there is a stable contact point.



The center frame directly behind the steering rack.